



Notes:

1. Pins 4,5,9,10 internally connected to case ground and lid
2. Pin 1 - signal in
3. Pin 2 - ground in
4. Pin 6 - signal out
5. Pin7 - ground out
6. Pin3,8 -case ground